



28-6, Gajangsaneopdong-ro,
Osan-si, Gyeonggi-do, 18103, Republic of Korea
TEL : +82-31-8077-5000 / FAX : +82-31-624-5310
<http://www.miniprinter.com>


sewoo

PRINT SERVICE PLUGIN MANUAL


Rev.B 05 / 2021

Aroot Co., Ltd.


The manual and product are protected by copyright.



1. How to use




- 01 Search **sewoo** in the Google Play Store and download the **Sewoo Print Service Plugin** shown in the left image.



- 02 After installing SEWOO Print Service Plugin, configure each one.




- 1 In the Connections - more Connection Settings - printing, activate the SEWOO Print Service Plug-in.
- 2 Enable Location and Storage in SEWOO Print Service Plugin App Permissions.



03 After running the app, search for connectable printers by **SEARCH BLUETOOTH DEVICES**. Click the list of printers to be connected to pair. After pairing, set the paper and emulation settings, and click the **Save** button to save the settings. After setting the paper, please disconnect or close the program.

- Emulation(ESC/POS, CPCL, ZPL)
- Media(Continuous, Gap, BlackMark)
- 58mm(2"), 80mm(3"), 104mm(4")

※ High-speed printing may not work depending on the printer F/W version.



04 Select the file you want to print (images, documents, web pages, etc.) and click the **Print** button in Options. If you see an item as shown in the second image, select the printer Bluetooth Mac Address at the top and click the **yellow print** button to print. In case of USB printing, select **USB POS Printer & USB Mobile Printer** at the top to print.